

**09991**

SANITOUCH® MANUAL HARD ROLL TOWEL DISPENSER

Made of high-impact plastic with a white housing that includes a provision for a custom deco strip. Dispenser automatically advances and cuts a nominal 12" of towel when activated by pulling exposed towel. No-touch dispensing system helps minimize the spread of dirt and germs. Dispenses one 8" and one 3.5" diameter roll with 1.5" cores. Features include emergency feed knob and choice of key-activated spring lock or push button operation. One per case.

Suggested mounting height is 48" maximum from the bottom of housing.

When installed properly and used with the corresponding product, this dispenser meets the ADA Standards for Accessible Design, local rules may vary.

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.