



ELECTRONIC TOUCHLESS HARD ROLL TOWEL DISPENSER

Made of a 22 gauge brushed stainless steel mounted to a steel grey backed enamel frame. The dispenser is designed to operate in one of two modes by positioning of the operation mode switch located below the sheet length selection switch:

Hidden mode - No paper is exposed; and a single sheet is automatically dispensed when a user's hand is placed beneath the unit.

Hang mode - A full single sheet is exposed; and when it is torn by a user, another full sheet is automatically dispensed.

Features include adjustable sensitivity, sheet length, and dispense delay. Dispenses one 8" diameter roll with 1.75" core plus a stub roll. No-touch dispensing system helps reduce the spread of dirt and germs.

Choice of key activated spring latch or push button operation. Operates on four (4) "D" size (included) or available AC adapter. Fits most 12" to 15" wide recessed folded towel dispenser cabinets with 4" or greater depth. One per case. Suggested mounting height: 48"

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.