



**29741**

## MOD\* NEXT GENERATION TOUCHLESS HARD ROLL TOWEL DISPENSER, WHITE

Made of high impact plastic. Housing has cover with opaque white center and smoked translucent sides with an opaque black back. Dispenser advances and cuts a nominal 11.75 inches of towel when activated. Dispenses one 8" diameter roll of 700' or 1150' product plus stub roll utilizing core plug mounting. Features include: Two operational modes, motor assist and hanging. A slight pull on hanging sheet starts motor to drive out and cut sheet in assist mode. In hanging mode, full sheet is exposed for user to remove with light pull. Hanging sheet is automatically replenished following variable delay if any. Features also include smart technology allowing no delay after each dispense, delay after each dispense or delay after two dispenses, variable delay time and choice of key-activated spring lock or push button operation. Operates on four D size alkaline batteries or AC adapter.

One per case.

**Suggested mounting height 48" from bottom of housing.**

### Product Codes

25630 KLEENEX® Hard Roll Towels -700'/roll

25700 SCOTT® High Capacity Hard Roll Towels -1150'/roll

*NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.*