



32508

MOD* ELECTRONIC TOUCHLESS CASSETTE SKIN CARE DISPENSER, 1.2 LITER, FAUX STAINLESS

Made of high impact plastic. Housing has a cover with faux stainless center and smoked translucent sides with an opaque black back. Automatically dispenses a one shot hand wash volume of soap or sanitizer when user places hand beneath the dispenser. Touchless system helps reduce the spread of dirt and germs. Uses a 1.2 liter recyclable refill. Incorporates low battery and low product lights for easier maintenance. Choice of key or push button opening. Operates on three D size alkaline batteries. One per case.

Suggested mounting height is 10" above counter or other obstruction.

When installed properly this dispenser meets the ADA Standards for Accessible Design, local rules may vary.

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.