



**39732**

## MOD\* CORELESS JRT TWIN BATHROOM TISSUE DISPENSER, FAUX STAINLESS

Made of high impact plastic. Housing has a cover with brushed metallic center and smoked translucent sides with an opaque black back. Designed to dispense two 9.38" diameter x 3.78" wide tissue rolls. Dispenser holds more than the equivalent, in length, of twelve standard rolls of bath tissue. Revised plunger design for greater durability. Dispenser is designed to minimize run-out, waste, and maintenance time. Features no door, no key and no core to throw away, and tear-off bars on both sides of dispenser opening. Sliding roll cover keeps one roll isolated and unusable until the other roll is sufficiently depleted. Hardware included for mounting. One per case.

**Suggested mounting height is 30" from the floor, 7-9" from the midline of the dispenser to the front of the toilet.**

**When installed properly and used with the corresponding product, this dispenser meets the ADA Standards for Accessible Design.**

*NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.*