



39712

MOD* SCOTTFOLD* FOLDED TOWEL DISPENSER, BRUSHED METALLIC

Made of high impact plastic. Housing has a cover with brushed metallic center and smoked translucent sides with an opaque black back. The dispenser accommodates up to 2 full and 1 half clips of towels to help reduce maintenance. Features key-activated spring lock or push-button operation and a hinged front cover. Incorporates overfill mechanism to minimize tears and tabs when dispenser is overfilled. Hardware included for mounting. One per case.

Suggested mounting height is 44" above the floor.

When installed properly, this dispenser meets ADA Standard 28 CFR Part 36 (1994).

Product Codes

13253 KLEENEX[®] SCOTTFOLD* Towels

01960 SCOTT[®] SCOTTFOLD* Towels

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.