



09992

## ELECTRONIC TOUCHLESS ROLL TOWEL DISPENSER

Made of high impact plastic with a smoked cover and a gray back with transparent window for viewing product level. Dispenser automatically dispenses a single sheet of paper when users' hand is placed beneath dispenser. No-touch dispensing system helps reduce the spread of dirt and germs. Dispenses one 8" diameter roll with 1.75" core plus a stub roll. Features include adjustable sensitivity, sheet length and delay between sheets. Also incorporates a sleep mode to shut down unit when lights are out to conserve battery life. Choice of key activated spring latch or push button operation. Operates on four D size alkaline batteries or AC adapter. One per case.

**Suggested mounting height is 48" maximum from the bottom of housing.**

**When installed properly and used with the corresponding product, this dispenser meets the ADA Standards for Accessible Design.**

*NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.*