



47092

SCOTT[®] MANUAL SLIMROLL^{*} TOUCHLESS HARD ROLL TOWEL DISPENSER, ORANGE CODE - BLACK

Made of high impact plastic. Housing has cover with opaque black center and smoked translucent sides with an opaque black back. Dispenser advances and cuts a nominal 10 inches of towel when activated by pulling exposed towel. No-touch dispensing system helps to minimize the spread of dirt and germs. Dispenses one 8" diameter, 580' roll. Features include quick load capability, emergency feed knob and choice of key-activated spring lock or push button operation. One per case.

Suggested mounting height is 48" maximum from the bottom of housing.

When installed properly and used with the corresponding product, this dispenser meets the ADA Standards for Accessible Design.

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.