



47604

## TOUCHLESS COUNTER MOUNT SKIN CARE DISPENSER

Made of high impact plastic with a chrome-plated dispensing head. Dispenser automatically dispenses soap when user's hand is placed beneath the dispensing head. SMART SHOT DISPENSING TECHNOLOGY\* delivers a perfect foam shot every time with no messy wasteful drips. Additional dispenser features include a low soap warning LED, low battery warning LED, selection switch for 1.5 L or 800ml refills and a selection switch for long and short sensor range. Battery pack installs into a lockable remote retainer with a 36" interconnection cable. Retainer can be secured either by hardware (included) or double-sided tape (not included). Dispenser can be powered by batteries (included) or AC Adapter / AC Splitter (both available separately). Dispenser is installed in a 1" minimum diameter hole in a countertop. Dispenser will accept 1.5 L or 800ml soap refills that easily snap into place. Each soap cartridge includes a tube that runs through the dispensing head so the soap never comes into contact with any of the dispensing parts, eliminating build-up and corrosion. Dispenser will not require soaking or system purging. One per case.

**When installed properly, this dispenser meets the ADA Standards for Accessible Design, local rules may vary.**

*NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.*