



48857

KIMBERLY-CLARK PROFESSIONAL™ ELECTRONIC TOWEL DISPENSER, SMOKE, 1.75" CORE SIZE

High-capacity electronic towel system, made of high-impact smoke-colored plastic, has a translucent cover which provides refill indication. No-touch dispensing system helps to minimize the spread of dirt and germs. Unit dispenses a nominal 11" of towel when activated by placing hand under the unit. A second sheet will dispense at 10% reduced length when activated within a few seconds of the first dispense. Dispenses one 8" diameter, 950' hard roll towel. Other features include a quiet dispensing system, quick-load capability, and choice of key-activated spring lock or push-button operation. Four D-Cell batteries included. One dispenser per case.

Suggested minimum height of 12" when installed above a counter.

Suggested mounting height is 48" maximum from the bottom of housing.

When installed properly and used with the corresponding product, this dispenser meets the ADA Standards for Accessible Design.

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.