



48860

SCOTT® ESSENTIAL™ ELECTRONIC TOWEL DISPENSER, SMOKE, PURPLE CORE

High-capacity electronic towel system, made of high-impact, smoke-colored plastic, has a translucent cover which provides refill indication. No-touch dispensing system helps to minimize the spread of dirt and germs. Unit dispenses a nominal 11" of towel when activated by placing hand under the unit. A second sheet will dispense at 10% reduced length when activated within a few seconds of the first dispense. Dispenses one 8" diameter, 950' hard roll towel. Features include a quiet dispensing system, quick-load capability, and choice of key-activated spring lock or push-button operation. Four D-Cell batteries included. One dispenser per case.

Suggested minimum height of 12" when installed above a counter.

Suggested mounting height is 48" maximum from the bottom of housing.

When installed properly and used with the corresponding product, this dispenser meets the ADA Standards for Accessible Design, local rules may vary.

NOTE: Unless otherwise noted, suggested mounting height is the distance from the floor to the bottom of the dispenser.